

## RoadRover Models

### 1. Special for VW Brand

#### [A2265VP for VW series](#)

Passat B5 Exclusive	2004 - 2005
Bora	1998 - 2005
Golf IV	1997 - 2003
Polo	2000 >
Transporter	2004 >

#### [A2270VS for VW series](#)

Passat B6	2005 - 2009
Jetta	2005 >
Golf V	2003 >
Caddy	2004 >
Touran	
Skoda Fabia	
Roomster	

### 2. Special for Skoda Brand

#### [A2270SM for Skoda Octavia](#)

### 3. Special for Toyota Brand

#### [A2270TCA for Toyota Camry](#)

Camry	2007
Camry	2008

#### [A2270TP for Toyota Prado](#)

Prado	2007
Prado	2008

#### [A2270TCO for Toyota Corolla](#)

Corolla	2007
Corolla	2008

#### [D2280TC for Toyota Crown](#)

Crown	2007
Crown	2008

#### [A2265TU for Toyota series](#)

Land Crusier2008	2008>
Hilux	2008>
RAV4	2006-2008>
Corolla	2007<
Prado	2007<
Camry	2006<

### 4. Special for Ford Brand

[A2265FF for Ford series](#)

Focus	2005 - 2008.4
Fiesta	2006 >
Fusion	2006 >

[A2269FM for Ford series](#)

Mondeo	2008>
Focus	2008.4.30>
S-max	2008>
C-max	2008>

**5. Special for Honda Brand**

[A2270HC for Honda CR-V](#)

CR-V	2007
CR-V	2008

[A2265HCl for Honda Civic](#)

[D2280HA for Honda Accord 2008](#)

**6. Special for Mazda Brand**

[A2265M3 for Mazda 3](#)

[A2265M2 for Mazda 2](#)

**7. Special for Hyundai Brand**

[A2265HS for HYUNDAI Santa Fe](#)

**8. Special for Chevrolet Brand**

[A2270CE Special for](#)

<a href="#">Chevrolet Epica</a>	2006 >
<a href="#">GMC Yukon</a>	2006 >

**9. Special for Nissan Brand**

[A2265NA for Nissan Qashqai](#)

[A2265NP for Nissan Patrol](#)

[A2270NT for Nissan New Teana](#)